



CRYE PRECISION

152 / BOTTLE POUCH



P/N: SPS-068

© CRYE PRECISION LLC. ALL RIGHTS RESERVED.
MADE IN THE U.S. FROM U.S. MATERIALS
WWW.CRYEPRECISION.COM

INSTALLATION INSTRUCTIONS


MOLLE ATTACHMENT



1 Pass end of attaching strap tabs through top row of PALS on platform.



2 Extend attaching straps so pouch is pulled tight against platform, pass attaching strap tabs through top bar on pouch, continue weaving until last row of PALS in engaged.



3 Pass attaching strap tabs through bottom bar on pouch, fold tab back on itself and tuck behind bottom PALS row.

AVS™ HARNESS ARM ATTACHMENT



1 Locate AVS™ Arm sleeve on back of pouch, separate Velcro.



2 Pass the AVS™ Arm through the sleeve on the back of the pouch.



3 Place in desired location, press **RRRRRRRRRRRRRRRRRRRRRR** of AVS™ Arm to secure in place.

BELT MOUNT



1 Secure attaching strap tabs through the webbing on the back of the pouch.



2 Locate belt sleeve on the back of the pouch.



3 Pass belt through sleeve and slide to desired location.